

## HOOPS WITH PURECRYSTAL CRYSTALS FIXING UV RESIN

By : Tiffanie Perles&Co



Easy



0 minutes

*How to glue PureCrystal on creoles ?*

#### How to stick PureCrystal Crystals on cabochons?

If you're in the mood for custom hoop earrings with PureCrystal crystals, you've come to the right place. We will present in this DIY video tutorial an original technique to fix your cabochons with set on openwork hoops and this technique will hold better than most glues for jewelry! This is possible thanks to the [UV LED resin](#). It is a resin that catalyzes or hardens thanks to UV rays. Unlike the two-component resin which has a catalysis time of several hours or even several days, the UV LED resin hardens in one minute thanks to a [UV LED lamp](#).  
With jewelry glue or classic resin it would have been almost impossible for you to carry out the tutorial presented here because you would then have to maintain your collage by hand for several tens of minutes in the first case and several hours in the other. Thanks to the UV LED resin you will only have to hold a minute!

Safety note: Use UV LED resin in a ventilated room, or under an extractor hood. Use gloves, mask and protective goggles in case of splashes.

Release date of the video on Youtube: Sunday February 9 at 9:00 am

Step 1:

Place the cabochons in the corresponding settings and fold the legs of the settings onto the PureCrystal cabochons.

2nd step:

Attach the first cabochon to your table with a fixed leg, cabochon towards the table, to prevent it from moving. Put UV LED resin inside the flat setting on the table (remember to protect your table because you will not be able to remove the resin once it hardens). Put a sufficient dose so that the resin is slightly above the edge of the hole and that it touches the creole. Place the creole on top where you want to affix the cabochon. Be aware that the resin shrinks when it catalyzes.

Step 3:

Press the lamp to trigger the UV rays and hold it above the creole and the cabochon with your other hand until it goes out. Do not look directly at the light of the lamp.

Step 4:

Once the cabochon is pre-glued to the hoop with the resin, put a new layer of resin on top of the hoops. There must be enough resin to cover the area of the creole in contact with the setting and the first catalyzed part of the resin. Trigger the lamp again.

Step 5:

Repeat steps 2 to 4 for the other cabochons as well.



Do not hesitate to show your creations on our Facebook page, in the Super club group of Perles & Co customers or on Instagram by quoting us with @perlesandco or with #perlesandco.

## Which material to use for Hoops with PureCrystal crystals fixing UV resin?

### SUPPLIES



Earring hoops 3 wires to decorate 48 mm fine Gold plated x2  
Ref. : BO-990  
Quantity : 1



UV-LED Resin Hard Padico - Star Drop x30g  
Ref. : OTL-348  
Quantity : 1



Chain Nose pliers Beadalon Econo  
Ref. : OUT-441  
Quantity : 1



PureCrystal Navette cabochon setting 10x5mm Gold-colored  
Ref. : SERTI-169  
Quantity : 2



Cabochon setting PureCrystal 1028/1088/1122 6mm Gold tone x1  
Ref. : SERTI-386  
Quantity : 4



Setting square - shaped for PureCrystal 4470 10 mm - Gold Tone x1  
Ref. : SERTI-594  
Quantity : 4



Mini UV LED lamp for DIY creation with UV LED resin x1  
Ref. : TECH-118  
Quantity : 1



PureCrystal Navette 4228 10x5 mm Aquamarine Ignite x1  
Ref. : WNV-249  
Quantity : 2



10mm PureCrystal 4470 Fancy Stone - Crystal Ignite x1  
Ref. : WST-225  
Quantity : 2



10mm PureCrystal 4470 Fancy Stone - Iris x1  
Ref. : WST-226  
Quantity : 2



6mm PureCrystal 1088 Round Stone - Crystal Ignite x1  
Ref. : WST-245  
Quantity : 2



6mm PureCrystal 1088 Round Stone - Iris x1  
Ref. : WST-246  
Quantity : 2

*Result*