

925 STERLING SILVER BALL CHAIN NECKLACE WITH GEMSTONE PENDANT

By: Lucie L PerlestiCo



 $\mathbf{Q}\mathbf{Q}\mathbf{Q}$

Easy

45 minutes



Want to start this new year with a jewel that follows your desires?

DIY: gemstone pendant necklace



Which material to use for 925 Sterling Silver Ball Chain Necklace with Genstone Pendant?

SUPPLIES

925 Sterling Silver 2mm cable chain (1x2) with faceted balls x50 cm

Ref. : CHR-498 Quantity : 1



Kit of 3 Pliers professional quality for jewelry - Chain nose pliers, Cutting pliers, Round nose

pliers

Ref.: OTL-580 Quantity: 1



Jewel Glue Hasulith 30ml

Ref. : OUTIL-007 Quantity : 1



Irregular nugget bead drilled 12-25 mm Smoky Quartz x1

Ref.: SEM-884 Quantity: 1



925 Sterling Silver Terminators for 1.1mm cords x4

Ref.: SL-1221 Quantity: 1



925 Sterling Silver 0.6mm flexible round Wire x1m

Ref.: SL-521 Quantity: 1



925 Sterling silver lobster clasp 8.5 mm x1

Ref.: SSU-167 Quantity: 1



steps

★ Step 1/4

Start by taking the length of chain you want to make your necklace. It can be worn as a choker or a necklace. Cut the desired length with a pair of wire cutters.

Using your Hasulith jewellery glue, apply a little glue to the ends of the chain so that you can insert it into the string ends.Let it dry for about 1 hour before handling your chain again.



★ Step 2/4

Once the glue has dried and your tips are securely attached, open the ring on your clasp with two jewelry pliers to connect it to one of the two tips.



★ Step 3/4

Thread the end of your silver wire through the hole in your bead. Using your jewellery pliers, form a loop large enough to be able to insert the end of your chain and vary your pendants. Once the loop is formed, wrap the silver wire around itself to lock it in place.





★ Step 4/4

With the wire remaining under the bead, make several turns around it, in the width or length of the stone according to your wishes. Block the remaining wire inside the hole of the bead if this one allows it (the holes of the stones have a variable diameter) by depositing a very small point of glue on it beforehand or twist it around another wire and cut it. Your pendant is ready to be threaded on your chain.



Result