

## THIN BRACELETS IN NATURAL PINK STONE

By : Agathe Perles & Co



Easy



35 minutes

*How to make an accumulation of bracelets with natural stones?*

Our Indian Summer collection features jewelry with natural stones. These are the ideal beads for jewelry that combines fashion and softness! Discover in this tutorial how to create a set of three pink bracelets combining pink quartz, pink tourmaline and pearly pearls. *Stacking* jewelry is a trend that's been in vogue for several seasons now, and can be applied to an accumulation of necklaces, earrings or bracelets, as in this case.

You'll need around 30 minutes to complete this tutorial, which doesn't require much in the way of materials. You'll need two flat-nose pliers and a pair of wire-cutters, as well as the materials indicated to make your 3 creations. Be careful to adapt the length of your bracelets to the size of your wrist, so don't hesitate to test with the wire before closing your bracelet.

These bracelets are also customizable thanks to the natural stones, which you can replace to suit your tastes. For example, you can replace the faceted rose quartz beads with Aventurine for a touch of green, Lapis Lazuli for a deep blue or Apatite with its turquoise blue. So you see, you can customize these bracelets to suit your mood!

If you reproduce this tutorial, don't hesitate to share your jewelry on social networks by tagging our Facebook page or Instagram account. We'd love to see what you come up with!

## Which material to use for Thin bracelets in natural pink stone?

### SUPPLIES



Wire protectors for 0.7mm wire - Fine Gold plated x20  
Ref. : ACC-929  
Quantity : 1



3-5mm Gemstone chip beads - Pink Tourmaline x40cm  
Ref. : CHIPS-100  
Quantity : 1



Tortue Nylon thread - Transparent 0.30 mm x100m  
Ref. : FCU-824  
Quantity : 1



Fine Gold plated springing clasp with tag 5mm x1  
Ref. : FRM-583  
Quantity : 2



Spring clasp 7 mm with extension chain - fine Gold plated x1  
Ref. : FRM-799  
Quantity : 1



2mm 316 Stainless Steel Round crimp beads - Gold Tone x25  
Ref. : INX-339  
Quantity : 1



5x1mm Heishi round beads - flat drilled discs - Fine Gold plated x10  
Ref. : LTZ-100  
Quantity : 2



Metal beads 4mm fine Gold plated x20  
Ref. : MET-073  
Quantity : 1



6x4mm Round Heishi beads - dyed mother of pearl - Ivory x4c1m  
Ref. : NA-778  
Quantity : 1



4mm Preciosa round faceted beads - Round Bead - Crystal Aurum Full x20  
Ref. : PCC-846  
Quantity : 1




Beads Faceted round beads 4 mm Quartz Rose x20  
Ref. : SP-537  
Quantity : 3



Heart beads 6mm fine Gold plated x4  
Ref. : TAL-277  
Quantity : 2

## SUPPLIES



Kit of 3 Pliers professional quality for jewelry - Chain nose pliers, Cutting pliers, Round nose pliers  
Ref. : OTL-580  
Quantity : 1



Crimping pliers Eco  
Ref. : OUTIL-024  
Quantity : 1

## steps

### ★ Step 1/9

Start by cutting a length of wire of about 20 centimetres, then slide a squeeze bead into the wire using flat-nose pliers. You can then add a wire protector. Slip the wire through the other part of the cable protector, and pass it through your squeeze bead as well. Using flat-nose pliers, push your crush bead against your wire protector. Then crush your crush bead with your flat-nose pliers. Cut off the excess wire, leaving a centimetre overhang.



### ★ Step 2/9

Thread the first pearly bead so that the return of the wired wire passes inside it, so that it is well concealed.



### ★ Step 3/9

Thread the beads in any order you like, taking into account the size of your wrist.





★ Step 4/9

You can repeat step 1 of the tutorial: slide on a pearl to be crushed, then a wire protector, passing the wire on both sides. Then, after bringing the pearl and wire guard as close as possible to the last pearly pearl, crush the pearl to be crushed with your flat-nose pliers.



★ Step 5/9

Using flat-nose pliers and round-tipped pliers, open one ring and slide it into the ring on the spring clasp. Close the first ring in the wire guard.



★ Step 6/9

Repeat this step with the tag fastener and attach it to the other side of the bracelet. Repeat this bracelet. You can make exactly the same bracelet again, or change the order of your beads as you wish.



★ Step 7/9

Repeat step 1 of the tutorial: slide on a crush bead, then a wire protector, passing the wire on both sides.



★ Step 8/9

Slide your beads in the order of your choice



★ Step 9/9

Attach the extension chain with an open ring to the end of the bracelet.  
Your three bracelets are now complete!



## Result

